



- * Notice this pin is on top?
- * Try it both ways to get the perfect fit.
- * Tighten everything down very tight when you find the fit.



Position the CLAWS the way they work the best for you, it's your choice

Positions in order of loading




3 Once here..., stand up.

1 START HERE

2 End up at about a 30-45 degree angle


To rotate push down on the grips and pivot the wheels over to the tail wheel.



STEP #1

STEP #2


Remember - end up on about a 30 to 45 degree angle.



STEP #3

Pull back and straighten it out





When you find your "perfect fit" tighten down the little set-screws on the CLAWS and on the big bolts down real tight.

